



# REMY STARTERS & ALTERNATORS

FOR SPRINTER VAN APPLICATIONS

---

The Trusted Brand for High Performance Starters and Alternators

# Remy Starters and Alternators for Sprinter Vans

Remy starters and alternators for Sprinter vans are made for the aftermarket with the same precision as the original equipment. Designed to fit perfectly and perform flawlessly, they are as good, or better, than the parts they replace.

Remy is recognized as the aftermarket leader in vehicle coverage. With monthly product releases on late model vehicle applications, we have built a comprehensive portfolio of starters and alternators for Sprinter vans.

- Manufactured to meet or exceed OE specifications for improved reliability and increased durability in all conditions
- 100% new premium replacement components that offer the quality and performance you can trust
- Designed to handle the electrical loads of today's Sprinter van applications

## STARTERS

Year	Engine (L)	Options	kW	Remy#
------	------------	---------	----	-------

### DODGE SPRINTER 2500/3500

#### 5 Cylinder

2006-05	2.7		2.2	17459
2004-03	2.7	w/ Bosch Starter	2.2	17459
		w/ Valeo Starter	2.2	17499

#### 6 Cylinder

2009	3.0		1.7	17627
2008-07	3.0		1.7	17627
	3.5		1.4	16021

### FREIGHTLINER 2500/3500

#### 4 Cylinder

2016-14	2.1		1.4	16324*
---------	-----	--	-----	--------

#### 5 Cylinder

2006-05	2.7		2.2	17459
2004-02	2.7	w/ Bosch Starter	2.2	17459
		w/ Valeo Starter	2.2	17499

#### 6 Cylinder

2016-2009	3.0		1.7	17627
2008-07	3.0		1.7	17627
	3.5		1.4	16021

### MERCEDES-BENZ 2500/3500

#### 4 Cylinder

2016-14	2.1		1.4	16324*
---------	-----	--	-----	--------

#### 6 Cylinder

2016-2010	3.0		1.7	17627
-----------	-----	--	-----	-------

# Industry-Leading Coverage for Sprinter Vans from 2002 to 2016

## ALTERNATORS

Year	Engine (L)	Options	Pulley	Amp	Remy#
------	------------	---------	--------	-----	-------

### DODGE SPRINTER 2500/3500

#### 5 Cylinder

2006-03	2.7	w/ 90 Amp Alt	6C	90	12610
		w/ 120 Amp Alt	6C	120	12611
		w/ 150 Amp Alt	6C	150	12612

#### 6 Cylinder

2009	3.0	w/ High Output Alt	7C	220	11004
		w/o High Output Alt	7C	180	12893
	3.0	w/ High Output Alt	7C	220	11004
		w/o High Output Alt	7C	180	12893
	3.5	w/ High Output Alt	6S	220	12939
		w/o High Output Alt	6S	180	12755

### FREIGHTLINER 2500/3500

#### 4 Cylinder

2016-14	2.1	w/o High Output Alt	6C	200	11241
---------	-----	---------------------	----	-----	-------

#### 5 Cylinder

2006-02	2.7	w/ 90 Amp Alt	6C	90	12610
		w/ 120 Amp Alt	6C	120	12611
		w/ 150 Amp Alt	6C	150	12612

#### 6 Cylinder

2016-13	3.0	w/ High Output Alt	7C	220	11004
		w/o High Output Alt	7C	180	11239
2012-10	3.0	w/ High Output Alt	7C	220	11004
		w/o High Output Alt	7C	180	12990
2009	3.0	w/ High Output Alt	7C	220	11004
		w/o High Output Alt	7C	180	12893
2008-07	3.0	w/ High Output Alt	7C	220	11004
		w/o High Output Alt	7C	180	12893
	3.5	w/ High Output Alt	6S	220	12939
		w/o High Output Alt	6S	180	12755

### MERCEDES-BENZ 2500/3500

#### 4 Cylinder

2016-14	2.1	w/o High Output Alt	6C	200	11241
---------	-----	---------------------	----	-----	-------

#### 6 Cylinder

2016-13	3.0	w/ High Output Alt	7C	220	11004
		w/ High Output Alt	7C	180	11239
2012-10	3.0	w/ High Output Alt	7C	220	11004
		w/ High Output Alt	7C	180	12990

## World-Class Technical Support

Remy's Technical Support is available to answer questions about the Remy Starters & Alternators for Sprinter Van Applications such as part number identification or electrical system troubleshooting.

Simply contact us via phone or email between 7am and 7pm CST.

Phone: 800.280.2737



**For quality Starters and Alternators trusted by automotive service professionals, visit [remyautomotive.com](http://remyautomotive.com) or contact your local Remy Sales Representative.**



Remy is a licensed trademark of BBB Industries, LLC

**BBB Industries, LLC**  
29627 Renaissance Blvd  
Daphne, AL 36526

[remyautomotive.com](http://remyautomotive.com)

RMYSPNTR-01 0919